

Pole Inserts - Fitting Instructions

1. Each insert is numbered to the corresponding section and must be placed into the male joint facing down, so it looks like a cup
2. When fitting a hollow insert please note the markings on the back, which must be placed into the male joint, facing down.
3. Upon fitting your insert you will note a slight lip where it will stop, apply **slight** pressure by turning your pole upside down and pressing down vertically until your insert 'clicks' into place
4. If you have trouble fitting the inserts place the insert into the male joint as far as it will go, then put into a cup of boiling water to soften, making it easier to slot in
5. If you are having trouble fitting the Pro-Alines, please remove the PTFE, place the insert in hot water to soften slightly and re-insert the PTFE once the insert has been fitted into your pole

If you are having trouble fitting your insert, or it doesn't look right PLEASE contact us as soon as possible and we will do our best to assist you. WE Products protects your pole, excessive force and/or gluing is not required for our inserts

Disclaimer: WE Products will not be held responsible for pole damage if the following instructions have not been followed and too much force or pressure has been applied

